
MAINFRAME

HOT RUNNER
TEMPERATURE
CONTROL SYSTEMS

*Instruction
Manual*



Table of Contents

Section 1	Mainframe Installation	4
1.1	Location	4
1.2	Connecting Input Power	4
1.3	Wiring for Different Power Sources	4
1.3.1	Schematic "A" (Standard Wiring)	4
1.3.2	Schematic "B" (European Standard)	4
1.3.3	Schematic "C" (Open Delta)	5
1.3.4	Schematic "D" (Single Phase)	5
1.3.5	Name Plate	5
1.3.6	Wiring Diagram.	6-12
Section 2	Module Installation and Secondary Wiring	13
2.1	Module Installation	13
2.2	Secondary Wiring	13
2.3	Check-out	13
2.4	Digital Current/Voltage Monitor	13
Section 3	Control System Troubleshooting	14
3.1	Temperature Oscillation	14
3.2	Temperature Too High	14
3.3	No Heat Indication	14
3.4	Troubleshooting Charts	15
3.4.1	Fault Classification	15
3.4.2	Power (Chart 2)	16
3.4.3	Module (Charts 3,4,5)	17-19

1.0 MAINFRAME INSTALLATION

Installation and service should be performed by qualified personnel only!

1.1 Location

The proper location is important for dependable service. The control system should be located so as to allow free air movement into and out of the mainframe. Consideration should be given to allow the least exposure to heat, dust, dirt, moisture, and corrosive vapors. The front of the system must be readily accessible for setup and adjustment purposes.

1.2 Connecting Input Power

- A) Check nameplate to make sure that the control system was wired at the factory for the power source to which it is to be connected. It is possible to change the wiring of the control system in the field to any of the power sources shown on the diagrams on the back of the unit. These diagrams are reproduced on the following pages for your convenience. See Section 1.3 for instructions on how to do this re-wiring.
- B) Remove back panel by removing the screws around its perimeter.
- C) Select input cable size and configuration based on load requirements and local electrical codes.
- D) Insert AC input cable through cable clamp provided on side of mainframe.
- E) Attach leads to terminal strip as shown on mainframe back panel for power source as shown on nameplate or as re-wired.
- F) Be sure to attach ground as shown on wiring diagram.
- G) Take up excess slack in cable and secure with strain relief clamp provided on the outside of the cabinet.
- H) Route AC input cable to a branch circuit disconnect switch and attach leads to the fused side of the switch. Be sure the ground lead is attached to a good earth ground.

1.3 Wiring Control System for Different Power Sources

See diagrams following this section or on rear of cabinet for the power sources for which this control system may be wired. These changes may be made without tools, although a pair of long-nosed pliers may be helpful. Changes are made by moving the wires that run from the control module connectors to the various power buses.

1.3.1 Schematic "A"

If the power source is not specified, the control system will be wired for Schematic "A" or 208-240 volt 3-wire, three phase power at the factory. This is standard in the U.S and Canada. For purposes of these instructions, it is assumed that the control system is being changed from Schematic "A" to the other schematics.

1.3.2 Schematic "B"

Schematic "B" is used in most countries in Europe; it is for 380/415 or 220/240 volt, 4-wire, three phase power. To make these changes, it is necessary to move the wire from pin #7 on each module connector to bus Mp/N. In addition, move one of the black wires from the fan to bus Mp/N. If the system has a C/V monitor, move the yellow, green, blue, and gray wires from the flat cable to Mp/N. Take one pilot light wire from the back of the main circuit breaker and extend it to bus Mp/N.

This arrangement is also valid for running the control system on 120/208, when 120 volt heaters are used. The control modules and C/V monitor must have their power transformer connections changed to 120 volts. The pilot light wiring does not have to be modified.

Please note that the large power wires that run from the AC power input block to the circuit breaker to the distribution buses are not the correct colors for European use. If the control system is to be used permanently in Europe, these wires should be changed. A kit with instructions is available from the factory. Control systems can be furnished with European colors at no charge, if specified at time of order.

1.3.3 Schematic "C"

This configuration is called "Open Delta," and is found in some areas of the United States. To change to this configuration, it is necessary to move the wire from pin #7 on each module connector to bus Mp/N. Move one of the black fan wires to Mp/N. Remove the rest of the wires from T/L3 and split them between R/L1 and S/I-2, to balance the load. If the system has a C/V Monitor, move the yellow, green, blue, and gray wires from the flat cable to Mp/N. Take one pilot light wire from the back of the main current breaker and extend it to bus Mp/N.

1.3.4 Schematic "D"


This schematic is for single phase operation. Move all of the wires from pin #7 of each module connector to R/L1; move all of the wires from pin #8 to S/L2.

1.3.5 Nameplate


Be sure to change the data on the nameplate to reflect changes made in the wiring.

1.3.6 Wiring Diagram

CONTROLLER POWER



WIRING DIAGRAM FOR RUNNERLESS MOLDING SYSTEM



WIRING CONNECTIONS	
ZONE 1	ROW 'A' TERMINALS 1+2
ZONE 2	ROW 'A' TERMINALS 3+4
ZONE 3	ROW 'A' TERMINALS 5+6
ZONE 4	ROW 'A' TERMINALS 7+8
ZONE 5	ROW 'B' TERMINALS 2+3
ZONE 6	ROW 'B' TERMINALS 4+5
ZONE 7	ROW 'B' TERMINALS 6+7
ZONE 8	ROW 'C' TERMINALS 1+2
ZONE 9	ROW 'C' TERMINALS 3+4
ZONE 10	ROW 'C' TERMINALS 5+6
ZONE 11	ROW 'C' TERMINALS 7+8
ZONE 12	ROW 'A+C' TERMINALS 9
ROW 'B' TERMINAL 8 IS NOT USED	

ZONE	5	6	8	12	ZONE
ZONE 1	WHT	RED	WHT	RED	WHT
ZONE 2	1	6	1	6	1
ZONE 3	2	7	2	10	2
ZONE 4	3	8	3	11	3
ZONE 5	4	9	4	12	4
ZONE 6	5	10	5	13	5
ZONE 7			6	14	6
ZONE 8			7	15	7
ZONE 9			8	16	8
ZONE 10			9	21	9
ZONE 11			10	22	10
ZONE 12			11	23	11
			12	24	12

REV. 12/24/95 RELEASED FOR PRODUCTION 1A

DATE: _____

DESIGNER: _____


REVISIONS: _____

THE WATKINS SYSTEM CUSTOMER SERVICE NUMBER IS 809A005U01

Part No. 809A005U01

Rev. 12/24/95

WIRING DIAGRAM FOR CE RUNNERLESS MOLDING SYSTEM



BEFORE POWER IS CONNECTED:

- USE OHM METER TO CHECK EACH HEATER POWER LEAD. RESISTANCE TO GROUND SHOULD BE GREATER THAN 20,000 OHMS.
- CHECK RESISTANCE* BETWEEN HEATER LEADS.
- CHECK CONNECTIONS OF RED AND WHITE LEADS TO INSURE PROPER CONNECTION TO THE CORRECT TERMINAL.
- USE OHM METER TO MEASURE BETWEEN RED AND WHITE LEADS. RESISTANCE SHOULD BE LOW.
- MEASURE BETWEEN EACH HEATER POWER LEAD AND EACH THERMOCOUPLE LEAD. RESISTANCE SHOULD BE GREATER THAN 20,000 OHMS.

5 ZONE		8 ZONE		12 ZONE		
ZONE	WHT	RED	WHT	RED	WHT	RED
ZONE 1	1	5	1	9	1	13
ZONE 2	2	7	2	10	2	14
ZONE 3	3	8	3	11	3	15
ZONE 4	4	9	4	12	4	16
ZONE 5	5	10	5	13	5	17
ZONE 6			6	14	6	18
ZONE 7			7	15	7	19
ZONE 8			8	16	8	20
ZONE 9				17	9	21
ZONE 10				18	10	22
ZONE 11				19	11	23
ZONE 12				20	12	24

5 ZONE		8 ZONE		12 ZONE		
ZONE	WHT	RED	WHT	RED	WHT	RED
ZONE 1	1	5	1	9	1	13
ZONE 2	2	7	2	10	2	14
ZONE 3	3	8	3	11	3	15
ZONE 4	4	9	4	12	4	16
ZONE 5	5	10	5	13	5	17
ZONE 6			6	14	6	18
ZONE 7			7	15	7	19
ZONE 8			8	16	8	20
ZONE 9				17	9	21
ZONE 10				18	10	22
ZONE 11				19	11	23
ZONE 12				20	12	24

HEATER
VOLTS MARKED ON HEATER

HEATER
WATTS MARKED ON HEATER

HEATER
RESISTANCE MARKED ON HEATER

* MEASURED RESISTANCE OHMS


240 VOLTS X 240 VOLTS = 820 WATTS ± 70 OHMS

NOTE: All grounds must be connected to mold to ensure operator safety.

DATE: 12/24/99
 RELEASED FOR PRODUCTION BY: CE HOTRUNNER SYSTEMS
 CUSTOMER: 809A005U02
 PART NUMBER: 809A005U02
 REVISIONS: 1

Input Power Wiring Diagram—Option A


208-240 Vac, 3-Phase, 3-Wire w/Ground Delta or “Y” Power Distribution System



Each module is powered from one of the three phases. Module One, for example, is powered from Phase 1, which is supplied by RL1 and SL2. Module Two is powered from Phase 2, which is supplied by SL2 and TL3. Module Three is powered by Phase 3, which is supplied by RL1 and TL3. At this point, the sequence repeats itself. For example, Module Four is connected the same as Module One to RL1 and SL2 and Module Six is connected the same as Module Three to RL1 and TL3. Module Seven is then connected to the same phase as Modules One and Four, etc. This method of connection ensures the greatest likelihood of line balance.

Input Power Wiring Diagram—Option B

380-415 Vac, 3-Phase,
4-Wire w/Ground “Y” Power
Distribution System



CAUTION NOTE: The voltages from line to line in this system are 380 to 415 volts. Severe damage to module and mainframe could result if this type of AC input system is connected in the 208-240 Vac configuration. This type of power distribution is very uncommon in the United States, but is the most common system used in other countries.

WARNING: If export of this system is intended, make sure that the wiring is reconfigured for the country where it is to be used. Please note that the 380-415 volt Power Distribution System is the same as the 208-240 Vac “Y” connection, except for the voltage levels and the use of the MPN to develop the 240 volts from the 380-415 volt system. Note that all modules in this system have one line connected to MPN and the other side connected to one of the 3-phase lines.

Example: Module One is connected to Phase 1, which is supplied by RL1 and MPN.


Module Two is connected to Phase 2, which is supplied by SL2 and MPN.

Module Three is connected to Phase 3, which is supplied by TL3 and MPN.

Module Four starts the sequence over again. It is connected to Phase 1 RL1 and MPN, etc.

Input Power Wiring Diagram—Option C

240 Vac, Single-Phase,
3-Wire w/Ground Power
Distribution System



The 240 volt single-phase connection only uses two power lines plus ground.


CAUTION: Only power conductors should be connected through the circuit breaker. Never make ground connections through a circuit breaker. Notice that the output of the circuit breaker is connected to terminal strips RL1 and SL2. Also, notice that ground is common with MP/N in this system. All modules in this system have to be connected to MP/N and either RL1 or SL2. Line balance is achieved by alternating between RL1 and SL2.

Example: Module One is connected to MP/N and RL1

Module Two is connected to MP/N and SL2, etc.

Input Power Wiring Diagram—Option D

208-240 Vac, Single-Phase,
2-Wire w/Ground 120 Vac,
Single-Phase 3-Wire w/Ground
Power Distribution System



The diagram to the left depicts two different wiring configurations. One is 208-240 volt, single-phase, 3-wire. Note that lines RL1 and SL2 are connected through the circuit breaker to the appropriate terminal strips. All modules in this system will be connected between RL1 and SL2. MP/N is common with ground and is not connected through the circuit breaker.

In the 120-volt connection (module connections shown within the dotted area), the 120 volts is developed between RL1 and MP/N and SL2 and MP/N. Again, ground and MP/N are not connected through the circuit breaker. Each module in this system will be connected to MP/N and either RL1 or SL2. Line balance is achieved by alternating between RL1 and SL2.

Example: Module One is connected to MP/N and RL1

Module Two is connected to MP/N and RL2, etc.

2.0 MODULE INSTALLATION AND SECONDARY WIRING

2.1 Module Installation

With the main circuit breaker in the "OFF" position, install each module being careful to fully seat in the connectors at the rear of the slot. Then press in the plastic lock at the bottom of the module.

2.2 Secondary Wiring

Carefully connect all heaters and thermocouples to their respective circuits, making sure that there are no short circuits. It is important that each thermocouple is wired to the zone that controls the associated heater.

2.3 Check-out

We recommend using Chart 1 of our troubleshooting procedure to ensure that the control system is working properly (See section 3.4.1).

2.4 Digital Current/Voltage Monitor

1-METER

A dual function, multi-range display is used to monitor either individual zone heater current in amperes or AC voltage of each phase of a three-phase input.

2-VOLTS/AMPS SWITCH

Determine whether meter functions as an Ammeter or Voltmeter. Refer to the serial number plate on the side of the mainframe to determine system input voltage requirements.

3-MAIN POWER SWITCH (DISCONNECT/BREAKER)

Used to turn the system ON or OFF.

4-MAIN POWER INDICATOR

Illuminates to indicate the Main Power Switch is on and that input power is applied to the system.

5-SELECTOR SWITCH

Used to select which zone or AC power line is being monitored.

In the R/L1, S/L2, or T/L3 positions the meter will indicate AC voltage of the line selected. The VOLTS/AMPS switch MUST be in the VOLTS position to read AC input voltage.


To measure individual zone current, place the VOLTS/AMPS switch in the AMPS position and select the zone to be monitored with the SELECTOR SWITCH. For systems that exceed 23 zones, place the switch in the "24" position and use the SELECTOR SWITCH in the upper cabinet to monitor zones 24 and higher.

WIRING:

3 WIRE 208-240 Vac
L1-brown, blue, violet
L2-red, yellow, gray
L3-green, orange

4 WIRE 380 Vac
L1-brown, violet
L2-red
L3-orange

NEUTRAL-yellow, green, blue, gray



3.0 CONTROL SYSTEM TROUBLESHOOTING

These procedures assume that your temperature control system has been installed in accordance with the installation instructions. Be sure that all wiring has been correctly done and that the power being supplied is the same as specified on the nameplate on the controller frame.

Problems that arise may be divided into two groups. The first is associated with the controller itself, the wiring, heaters, and thermocouples. This group is characterized by abnormal indications on the controller modules, such as blinking lights and displays or pilot lights "off." We have developed a set of troubleshooting charts to help you locate these problems.

The second group of problems are associated with design of the mold and hot runner system or with processing conditions. These problems are often more difficult to diagnose and to repair. Outlined below are some of the common problems we have found.

3.1 Temperature Oscillation

This is usually caused by the location of the thermocouple being too far away from the heater it is controlling. In order to provide proper control, the thermocouple should be located between one-half and one inch of its heater. Oscillation during processing can also be caused if the melt temperature is significantly above or below the set point of the zone.

3.2 Temperature Too High


This is usually caused either by heat from an adjacent zone or from having the melt temperature above the set point of that zone. This problem is also caused if the TC is not wired to the same control module as the corresponding heater.

3.3 No Heat Indication


Some of the hardware problems that cause this indication are described in the chart section of this procedure. It is also the indication that appears when something has occurred electrically to upset the microprocessor in the control module. It corresponds to the "Tilt" light on a pinball machine. It is reset by turning the power switch on the module off and then on. A random occurrence is not cause for concern. Should it happen regularly, however, it indicates that there is more interference on the power line to the control system than the filtering in the power supply can accommodate. The solution usually is to connect the controller as close to the electrical service entrance as possible, and not to the molding machine where the motors and solenoids cause electrical interference.

3.4.0 CONTROLLER TROUBLESHOOTING CHARTS


3.4.1 CONTROLLER TROUBLESHOOTING CHART 1
FAULT CLASSIFICATION




3.4.2 CONTROLLER TROUBLESHOOTING CHART 2
POWER




3.4.3 CONTROLLER TROUBLESHOOTING CHART 3
MODULE



3.4.3 CONTROLLER TROUBLESHOOTING CHART 4
MODULE (CONTINUED)



3.4.3 CONTROLLER TROUBLESHOOTING CHART 5
MODULE (CONTINUED)



Two-Year Limited Warranty

THIS EQUIPMENT IS WARRANTED TO BE FREE FROM DEFECTS OF MATERIAL AND WORKMANSHIP. IT IS SOLD SUBJECT TO OUR MUTUAL AGREEMENT THAT THE LIABILITY OF THE MANUFACTURER IS TO REPLACE OR REPAIR THIS EQUIPMENT AT ITS FACTORY, PROVIDED THAT IT IS RETURNED WITH TRANSPORTATION PREPAID WITHIN TWO (2) YEARS OF ITS PURCHASE.

THE PURCHASER AGREES THAT THE MANUFACTURER ASSUMES NO LIABILITY UNDER ANY CIRCUMSTANCES FOR CONSEQUENTIAL DAMAGES RESULTING FROM ITS USE OR FROM IMPROPER HANDLING OR PACKAGING OF SHIPMENTS RETURNED TO THE FACTORY.

COMPONENTS WHICH WEAR OR WHICH ARE DAMAGED BY MISUSE ARE NOT WARRANTED. THESE INCLUDE CONTACT POINTS, FUSES, ELECTROMECHANICAL RELAYS, AND TRIACS. UNITS WHICH HAVE BEEN MODIFIED BY A CUSTOMER IN ANY WAY ARE NOT WARRANTED.

Other than those expressly stated herein, THERE ARE NO OTHER WARRANTIES OF ANY KIND, EXPRESS OR IMPLIED, AND SPECIFICALLY EXCLUDED BUT NOT BY WAY OF LIMITATION, ARE THE IMPLIED WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND MERCHANTABILITY.

IT IS UNDERSTOOD AND AGREED THE SELLER'S LIABILITY WHETHER IN CONTRACT, IN TORT, UNDER ANY WARRANTY, IN NEGLIGENCE OR OTHERWISE SHALL NOT EXCEED THE RETURN OF THE AMOUNT OF THE PURCHASE PRICE PAID BY THE PURCHASER AND UNDER NO CIRCUMSTANCES SHALL SELLER BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES. THE PRICE STATED FOR THE EQUIPMENT IS A CONSIDERATION IN LIMITING SELLER'S LIABILITY. NO ACTION, REGARDLESS OF FORM, ARISING OUT OF THE TRANSACTIONS OF THIS AGREEMENT MAY BE BROUGHT BY PURCHASER MORE THAN ONE YEAR AFTER THE CAUSE OF ACTION HAS ACCRUED.

SELLER'S MAXIMUM LIABILITY SHALL NOT EXCEED AND BUYER'S REMEDY IS LIMITED TO EITHER (i) REPAIR OR REPLACEMENT OF THE DEFECTIVE PART OR PRODUCT, OR AT SELLER'S OPTION (ii) RETURN OF THE PRODUCT AND REFUND OF THE PURCHASE PRICE, AND SUCH REMEDY SHALL BE BUYER'S ENTIRE AND EXCLUSIVE REMEDY. THE SPECIFICATIONS PUT FORTH IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE.