



Long Life Ambient CO Detector



Functions

- Measures: CO 1 to 999 ppm

Features

- Preset alarms
- 3-Color warning light
- Audible alert
- MAX capture
- Data hold
- Low battery indicator
- CO detection 1 to 999 ppm
- Backlit display
- One button auto zero
- 3-Year limited warranty

Applications

CO detection for contractors working in environments with potentially high CO concentrations
First responder responsible for plant safety
Confirm implementation of government standards for CO exposure





Includes

- CO Detector (C071A)
- Holster w/ Belt clip
- Battery (9V)
- Owners Manual (17086)

Specifications

Range	0 - 999 ppm
Resolution	1 ppm
Accuracy	±(3% of reading + 1 ppm)
Visual	Green 2 - 9 ppm Yellow 10 - 34 ppm Red > 35 ppm
Audible	>35 ppm increasing frequency w/concentration
Battery	9V standard alkaline
Ambient Temp	32° to 104°F (0° to 40°C)

Exposure to CO: Important Numbers To Remember:

- 9 PPM Max allowable exposure for living area (ASHRAE standard)
- 35 PPM Max exposure for 8 hr work day (OSHA)
- 800 PPM Symptoms within 45 minutes - Death within 2 to 3 hrs
- 12,800 PPM Death within 1-3 minutes

Downloads



Manual



Data Sheet

H25-947



Made in UK